





TRENTON


Manual






52278 DRESSOIR 240x42x75 cm






52279 DRESSOIR 211x42x75 cm





52278 LOWBOARD 240x42x45/56 cm



52281 LOWBOARD 210x42x45/56 cm





52282 LOWBOARD 180x42x45/56 cm






52283 DRESSSETTE 150x42x133 cm

52284 STORAGE CHEST 95x42x191 cm




TOOL(S) NEEDED (not included)




ELEMENTS

ITEM(S)




52278 DRESSOIR 240 cm




52279 DRESSOIR 211 cm


Option: with legs




52278 LOWBOARD 240 cm




52281 LOWBOARD 210 cm



52282 LOWBOARD 180 cm






52283 DRESSSETTE 150 cm




52284 STORAGE CHEST 95 cm


HARDWARE (included)

ID	Hardware	52278	52279	52278	52281	52282	52283	52284
		DRESSOIR 240 cm	DRESSOIR 211 cm	LOWBOARD 240 cm	LOWBOARD 210 cm	LOWBOARD 180 cm	DRESSSETTE 150 cm	STORAGE CHEST 95 cm
A	 Bolt M6x20 mm	4	4	4	4	4	4	0
B	 Bolt M6x25 mm	8	8	8	8	8	8	8
D	 Washer	12	12	12	12	12	12	8
E	 Allen key with ball end	1	1	1	1	1	1	1
I	 Leg	2	2	2	2	2	2	2
J	 Central leg	1	1	1	1	1	1	0


1





2




3



4




5




ELEMENTS

ITEM(S)


Option: with plinth



52278 Lowboard 240 cm





52281 Lowboard 210 cm




52282 Lowboard 180 cm



HARDWARE (included)

ID	Hardware	52278	52279	52278	52281	52282	52283	52284
		Dressoir 240 cm	Dressoir 211 cm	Lowboard 240 cm	Lowboard 210 cm	Lowboard 180 cm	Dressette 150 cm	StorageChest 95 cm
C	 Bolt M6x35 mm	0	0	8	8	8	0	0
D	 Washer	0	0	8	8	8	0	0
K	 Plinth	0	0	1	1	1	0	0


1





2





3



4




5




ELEMENTS

ITEM(S)


Option: hang to the wall







52278 Lowboard 240 cm



52281 Lowboard 210 cm



52282 Lowboard 180 cm



ASSEMBLY SET SAFETY WARNING

GB: We **STRONGLY** recommend you to secure the furniture to the wall.

NL: Wij adviseren u **ZEER STERK** om uw meubel tegen de muur te bevestigen.

FR: Nous vous conseillons **FORTEMENT** de fixer votre meuble au mur.

DE: Wir empfehlen Ihnen **DRINGEND** Ihr Möbel an der Wand zu befestigen.



GB: Buy the correct screw and plug suitable for the wall.

NL: Koop de juiste schroef en plug die geschikt is voor de betreffende muur

FR: Veillez à acheter les vis et chevilles correspondant à votre type de mur.


DE: Kaufen Sie bitte richtige Dübel für Ihre Wand und dazu passende Schrauben.

Dimensions for wall assemble




ELEMENTS


ITEM(S)




52278 DRESSOIR 240 cm



52279 DRESSOIR 211 cm



52283 DRESSETTE 150 cm





52284 STORAGE CHEST 95 cm



HARDWARE (included)

ID	Hardware	52278	52279	52278	52281	52282	52283	52284
		DRESSOIR 240 cm	DRESSOIR 211 cm	LOWBOARD 240 cm	LOWBOARD 210 cm	LOWBOARD 180 cm	DRESSETTE 150 cm	STORAGE CHEST 95 cm
F	Shelf support 	4	4	0	0	0	4	8
G	Glass shelf 	1	1	0	0	0	1	2


1



2




3




ELEMENTS


ITEM(S)



52278 Lowboard 240x42x45/56 cm



52281 Lowboard 210x42x45/56 cm




52282 Lowboard 180x42x45/56 cm

HARDWARE (included)


ID	Hardware	52278	52279	52278	52281	52282	52283	52284
		Dressoir 240 cm	Dressoir 211 cm	Lowboard 240 cm	Lowboard 210 cm	Lowboard 180 cm	Dressette 150 cm	StorageChest 95 cm
H	 Wire cover	0	0	1	1	1	0	0

Cable manager cover option:


1) Please apply first masking tape on the location indicated below (to avoid damages on the top)



52278 Lowboard 180 cm




52281 Lowboard 210 cm




52282 Lowboard 240 cm


2) Mark exactly the position where to drill, on the location indicated below:



52278 Lowboard 180 cm




52281 Lowboard 210 cm





52282 Lowboard 240 cm

3) Drill the hole with $\varnothing$ 50 mm tool (tools are not included),






OR




4) Remove the masking tape and remove dust

5) insert the cable management cover (F)







HOW TO FIX HIGH ITEMS AGAINST THE WALL



52283 Dressette 150x42x133 cm




52284 Storage Chest 95x42x191 cm




ASSEMBLY SET SAFETY WARNING

GB: We STRONGLY recommend you to secure the furniture to the wall.
NL: Wij adviseren u ZEER STERK om uw meubel tegen de muur te bevestigen.
FR: Nous vous conseillons FORTEMENT de fixer votre meuble au mur.
DE: Wir empfehlen Ihnen DRINGEND Ihr Möbel an der Wand zu befestigen.


GB: Buy the correct screw and plug suitable for the wall.
NL: Koop de juiste schroef en plug die geschikt is voor de betreffende muur.
FR: Veillez à acheter les vis et chevilles correspondant à votre type de mur.
DE: Kaufen Sie bitte richtige Dübel für Ihre Wand und dazu passende Schrauben.





TWO PERSONS



NOT INCLUDED




NOT INCLUDED






HOW TO ADJUST / REMOVE DOOR(S)


Tools




Installation




Removal




Height adjustment



Overlay adjustment




Depth adjustment






HOW TO ADJUST / REMOVE / INSERT DRAWER(S)


Adjust height of drawer by turning the wheels on each side (individually)




Remove drawer by holding the handle



Insert drawer by sliding at a slight angle




Secure drawer by pushing it inward





HOW TO CONNECT TRANSFORMER TO LED





READY! ENJOY YOUR NEW FURNITURE AND
PLEASE READ OUR PASSPORT FOR
MAINTAINING YOUR FURNITURE PROPERLY



FR

Pensez à
donner ou recycler.



Association

ou



Magasin

ou



Déchèterie

<https://quefairedemesdechets.fr>